See Parts Photos and Motor/Shaft Replacement Instructions at www.floking.com



IMPORTANT!
For repairs outside of the factory, you must order LAB PBBH (Pump/Motor Base, Body & Impeller Housing) as a single welded unit to avoid machining operations associated with separate purchase of Base, Body or Housing alone. Specify pump body length when ordering. To determine pump body length, see Lab Series Specs at www.floking.com and measure the "A" Dimension.